

## APPLICATION NOTE Lumenera Ethernet Camera

### Restoring Camera Default Settings February 2005

#### Restoring the Image Parameters to Factory Default Values

##### Using a Web Browser:

1. Connect to the camera over a LAN through a web browser (e.g. Internet Explorer).
2. From the web interface, go to the “Camera Settings” tab.
3. Select the “Default Settings” hyperlink.

##### From a Telnet Interface:

1. Connect to the camera over a LAN using a telnet interface.
2. Type the command: `luether put_settings_from_property default_image_params` into the interface.

#### Restoring All Camera Parameters to Factory Default Values

##### Using the “Factory Reset” Button:

1. Turn off the camera by disconnecting the power cable.
2. Locate the small hole next to the serial port on the back of the camera.
3. Insert a pin or paperclip into the hole to depress the “Factory Reset” button. The button will “click” as it is pressed down.
4. While holding down the “Factory Reset” button restore power to the camera.
5. Continue holding down the “Factory Reset” button until the orange LED on the Ethernet connector blinks (approximately 30 seconds.)



**Note:** By restoring all parameters to their factory default values, the camera network settings may need to be reconfigured to work with the existing network.